

Quantec


Wiring instructions for Quantec Stainless Steel Programmable Call Points (all variants)


This instruction leaflet shows examples of two common wiring methods for Quantec Stainless Steel Programmable Call Points (all variants) with connections to typical slave devices. One method is shown adjacent, the other appears overleaf.

For detailed wiring, installation and programming information - including important compatibility information relating to a master call point's optional special programming functions - please refer to the main Quantec Installation manual, document no. DNU6012001.

Important note regarding IR devices:

Due to the high-risk environments in which infrared devices are likely to be used, be sure to install them so the best possible reception is achieved. If in doubt, contact your supplier for advice.





Quantec

Wiring instructions for Quantec Stainless Steel Programmable Call Points (all variants)

This instruction leaflet shows examples of two common wiring methods for Quantec Stainless Steel Programmable Call Points (all variants) with connections to typical slave devices. One method is shown adjacent, the other appears overleaf.

For detailed wiring, installation and programming information - including important compatibility information relating to a master call point's optional special programming functions - please refer to the main Quantec Installation manual, document no. DNU6012001.

Important note regarding IR devices:

Due to the high-risk environments in which infrared devices are likely to be used, be sure to install them so the best possible reception is achieved. If in doubt, contact your supplier for advice.